
WIRE COLOR CHART
BLACK BLK
BROWN BRN
BLUE BLU
DARK BLUE DK BLU
DARK GREEN DK GRN
GREEN GRN
GRAY GRY
LIGHT BLUE LT BLU
LIGHT GREEN LT GRN
ORANGE ORG
PINK PNK
PURPLE PPL
RED RED
TAN TAN
WHITE WHT
YELLOW YEL
IGNITION SWITCH
COMPONENT NAME
FUSIBLE LINK
STARTER RELAY
BATTERY
AMMETER
STARTER MOTOR
NEUTRAL START SWICTH
TO A/C SYSTEM
M/T
A/T
WIRE COLOR
SPLICE OR CONNECTOR
OIL PRESSURE SWITCH
ALTERNATOR
VOLTAGE REGULATOR
CONDITIONS WHEN POWER IS APPLIED
HOT IN START OR RUN
FUSE 10 10A
CHECK ENGINE INDICATOR
BULB
IGNITION CONTROL UNIT
IGNITION COIL
SPARK PLUGS
OXYGEN SENSOR SOLENOID
OXYGEN VACUUM DELAY SWITCH
ELECTRIC CHOKE
TERMINAL NUMBER
ENGINE CONTROL MODULE
OXYGEN SENSOR
CASE GROUND
GROUND
SOLENOID
COOLANT SWITCH
IDLE STOP SWITCH AND SOLENOID
OTHER SYSTEM REFERENCE
MODEL OPTIONS BRACKET
W/ A/C
W/O A/C